

(EN) Set up a net

1) Preparation

Clear the planned fenceline of tall grass, weeds, brush or other obstacles.



2) Unboxing

Remove the black cords from the unpacked net and roll it up until you can lift the stakes collected as „one pack“. The start post is to be identified by a bar-code tag.



3) Fenceline

Holding the pack of posts in one hand, walk backwards and place one post at a time. Unfold the entire roll of netting. Place each post in the correct order along the desired fenceline.



4) Raise the net

Drive the ground nails of the posts into the ground little by little, following the fence line. Tighten the netting in between just enough so that it stands well. If the net is too tight, it cannot adapt to uneven terrain; if it is too loose, it will hang down.



5) Start, Ends and Corners

To stabilise the net and make it even more solid, now tension the posts outwards at the start and end and at the corners using the cords and pegs provided.




6) Dismantling/remodeling

Remove the connections and tensioning ropes. Pull the posts out of the ground and lay the net flat on the ground. Gradually gather the posts back into a pack, folding the net in half in between. Lay the folded net on the ground and roll it towards the posts. Tie the roll tightly into a bundle with the ropes.

7) Netting Repair

If the net is torn in certain spots, simply connect the loose ends of the conductor material with LitzClip® without using any tools. Information and repair kits can be found at <https://www.ako-agrar.com/de/litzclip> or in specialist shops.



8) To be noted!

Animals that are not yet familiar with the net as a barrier have an increased risk of becoming entangled in the net and should be closely supervised, especially at the beginning. The net will not deter animals that flee in panic or are not adequately supplied with food and water from attempting to escape. We advise adults to keep small children away from nets and not to let them play near them.

